
Working Mode:

This device has two working modes, one is normal and code that is, the other is a stored pattern.

1, Entry the working mode Settings



Entry setting

2, Choose mode



Normal mode



Inventory mode

3, Inventory mode setting

If you choose the inventory model, then you can choose the function. Inventory mode setting

If you choose the inventory model, then you can choose the function.



Data statistics



Upload data



Clear data

Note: when you store the data and has been released, you also need to empty the existing scanning clear data. Because the device don't delete the last time the data stored by default. Recommended inventory good configuration and back to normal mode after power off.